# Giotto-Top TEACH

**IO**-Link



TECHNICAL CATALOGUE 06-2024





## GIOTTO TOP TEACH: Digital 24V, AS-i Bus, IO-Link



**CERTIFICATIONS** 

2014/30/EU-EMV 2011/65/ EU-RoHS ANSI/UL 94

TECHNICAL DATA			
Casing material	PA66 + PA6 (GF+GB)30X,PA6I/6T		
Gaskets material	NBR		
Protection class	IP67		
Air inlet and discharge connections diameter	1/8" BSP		
Air hoses connections	Ø6 mm std. / Ø6,35 (1/4") su richiesta Ø6 mm std. / Ø6.35 (1/4") on request		
Air supply pressure	Da 6 bar (87 psi) a 7 bar (101,5 psi) From 6 bar (87 psi) to 7 bar (101.5 psi)		
Vibrations/Shocks	Vibration (sinusoidal) test according to IEC 60068- 2-6 Handling shocks according to IEC 60068-2-31		
Storage temperature	-10+25 °C		
Air supply	Classe 2, 4, 3 ISO 8573-1 Class 2, 4, 3 ISO 8573-1		
Venting system	Snap-in Protective vent		

To check the configuration of electrical connections of the various accessories available for the control unit, Bardiani Valvole recommends to refer to Use and maintenance manual. For more information about control unit configuration, please to get in touch with Bardiani Valvole technical department.

### **GIOTTO TOP TEACH: 24V**

TECHNICAL DATA		
Power supply	18 to 28 V DC	
Residual ripple	max. 10%	
Max. power consuption	less than 5 W	

## GIOTTO TOP TEACH: AS-i INTERFACE

TECHNICAL DATA			
Power supply 29.5 to 31.6 V DC			
Max. current consuption	less than 160 mA		
1/0 configuration 7 hex (4 inputs / 4 outputs)			
ID code A hex			
Extended ID code 1	7 hex		
Extended ID code 2	E hex (see note below)		
Profile	S-7.A.E		

Bit configuration table				
Data bit	D3	D2	D1	DO
Input	External sensor S4	Position S3	Position S2	Position S1
Output	Not used	Solenoid valve UL	Solenoid valve LL	Solenoid valve MS
Parameter bit	Р3	P2	P1	РО
Output	Not used	Not used	Not used	Not used

#### Legenda

MS = main stroke, LL = lower lift, UL = upper lift

## **GIOTTO TOP IO-LINK**

TECHNICAL DATA			
Power supply	18 to 30 V DC		
Max. current consuption port class A	typ. 170 mA at 18 V, for 3 solenoid valves		
IO-Link specification	V1.1.2		
SIO-Mode	No		
Vendor ID	0x0743 (=1859)		
Devide ID	Port class A 0xBADA01 (12245505)		
Trasmission rate	230.4 kbit/s		
Frame type in operation	TYPE_2_V		
Min. Cycle time	5ms		
Data storage	Yes		
Max. cable lenght	20 m		

## **GIOTTO TOP TEACH**SOFTWARE FUNCTIONS

FUNCTION	VERSION		
Basic functions	24 V DC	AS-Interface	IO-Link
Teach function of the position measuring system	✓	✓	✓
Manual override solenoid valves (mechanical)	<b>√</b>	<b>√</b>	✓
Position feedback process valve via \$1\$4	✓	✓	✓
Feedback signal current valve position (intermediate position) in 0.1 mm resolution			✓
Optical position feedback	✓	✓	✓
Change of the colours of the optical position feedback possible	✓	✓	✓
Locating function (for AS-i profile S-7.A.7 on request)			<b>✓</b>
BüS communication interface (for Bürkert COMMUNICATOR)	✓	<b>✓</b>	✓

FUNCTION	VERSION		
Parametrisation	24 V DC	AS-Interface	IO-Link
Definable safety position in case of bus error			✓
Fail-safe positions are defined in the event of power and compressed air failure	✓	✓	✓
Deactivation of local operation (Lock function)			✓
Factory reset function (reset to factory setting)	✓	✓	✓
Output	Not used	Not used	Not used

FUNCTION	VERSION		
Diagnosis	24 V DC	AS-Interface	IO-Link
Counter switching cycles of solenoid valves	✓	✓	✓
Counter operating hours	✓	✓	✓
Maintenance/service notification (feedback when limit value for MS is exceeded)	✓	✓	<b>✓</b>
Active diagnostic messages (via Bürkert COMMUNICATOR)	<b>√</b>	<b>√</b>	<b>✓</b>
Maintenance reset (to reset counter values)	✓	✓	<b>✓</b>
Feedback Teach error	<b>√</b>	✓	<b>✓</b>
Feedback over-temperature			✓
Feedback communication error		✓	<b>√</b>
Tolerance band of end position detection	✓	✓	<b>√</b>
Tolerance for switching time overrun			<b>√</b>
Detection of under-voltage and over-voltage of the power supply	✓	✓	✓
Trigger maintenance function			✓
Log function for error cases (via Bürkert COMMUNICATOR)	✓	✓	✓

FEEDBACK / COLORS	YELLOW	YELLOW	GREEN	WHITE	WHITE	WHITE
S1	I	0	0	I	0	0
52	0	0	I	0	0	0
S3	0	I	0	0	I	0
S4	0	I	0	I	0	I

SINGLE MOVEMENT ACTUATOR (i.e. single seat valves, butterfly valves, bal valves, etc).			
POSITION COLOR FEEDBACK SIGNAL			
Valve closed	Yellow	S1	
Valve open	Green	S2	

DOUBLE SEAT MIX PROOF VALVES			
POSITION	COLOR	FEEDBACK SIGNAL	
Valve closed	Yellow	S1	
Valve open	Green	S2	
Upper lift	Yellow	S1	
Lower lift	White	S3	

DOUBLE SEAT MIX PROOF VALVES WITH EXTERNAL UPPER LIFT SENSOR				
POSITION	COLOR	FEEDBACK SIGNAL		
Valve closed	Yellow	S1		
Valve open	Green	S2		
Upper lift	White	S1+S4		
Lower lift	White	S3		

COLOR		POSITION SENSOR INSTALLED		
GI TTO		Open		
	GIO TTO	Closed		
Only for double seat valves	GIOTO GIOTO	Upper lift		
	GICTTO O	Lower lift		
	GILL TO	Error		

The association of LEDs colours with valve positions complies with standards EN60204 and EN61310.

	CONNECTIONS TYPE	24V	AS-i	IO-Link Port Class A	IO-Link Port Class B
	Threaded connection for cable gland PG11	✓			
	Threaded connection for cable gland M20x1.5	<b>✓</b>			
	7-pins wiring connector	√ 1/2 sensors +1/2/3 solenoid valves			
	M12 4-pins wiring connector		✓	<b>✓</b>	
WIRING CONNECTION	M12 5-pins wiring connector in accordance with IEC 61076-2-101	1 sensor +2 solenoid valves NC 2 sensors +1 solenoid valves NC 2 sensors +1 solenoid valve NC + 1 solenoid valve NO with joint control electronics	✓		✓
	M12 8-pins wiring connector in accordance with IEC 61076-2-101	√ 1/2/3 sensors +1/2/3 solenoid valves			
RING CONNECTION	M12 12-pins wiring connector in accordance with IEC 61076-2-101	√ 1/2/3/4 sensors +1/2/3 solenoid valves			

## RECOMMENDATIONS

- Consultation of the "Instruction, Use and Maintenance Manual" is mandatory prior to the installation, use and maintenance of the products of all Products. All the information, indications, specifications, technical details provided herein are based on test data which the Manufacturer Bardiani Valvole S.p.A. holds to be reliable nevertheless the above is not deemed to be assumed as fully exhaustive inasmuch as not every possible use has been envisaged.
- All the illustrations and drawings provided are to be intended as indicative and therefore not binding, the illustrations being for presentation purposes only.
- It is the Buyer's duty to assess the suitability of the Products
  for the use he intends to make of the same prior to placing the
  order as he/she will take the risks and accept liability in case of
  incorrect choice and use of the Products.
- The Manufacturer strongly recommends the Buyer to contact their sales team and request any information that might be needed in relation to the specifications and uses of the Products.
- The information provided in this manual refers to the standard products manufactured by Bardiani Valvole S.p.A. and therefore cannot be assumed to apply to customized products as well.
- Bardiani Valvole S.p.A. reserves the right to amend and/or integrate and/or update the data and/or information and/or technical details relative to Products at any time and without prior notice. Please visit the website www.bardiani.com, where the latest updated of the "Instruction, Use and Maintenance Manual" can be found".
- The content and validity of the warranty covering the Products of Bardiani Valvole S.p.A are dealt with in the relevant section in the "Instruction, Use and Maintenance Manual" which constitutes an integral part of the Products themselves.
- Bardiani Valvole S.p.A., shall not in any way be held liable for immaterial, indirect and consequential damages, such as (by way of example only), damages or loss of business, contracts, opportunities, time, production, profits, goodwill, image etc..





via G. di Vittorio, 50/52 - 43045 Fornovo di Taro (PR) - Italy tel. +39 0525 400044 - Fax +39 0525 3408 bardiani@bardiani.com - service@bardiani.com www.bardiani.com